

PITWRAP® B100 JACKETING

Description and Area of Application

PITWRAP® B100 jacketing is a self-sealing aluminum butyl laminate used for protecting above ground FOAMGLAS® insulation systems on above and below ambient service pipelines. Protective jacketing must be used over the PITWRAP® B100 jacketing for UV protection. Manual pressure seals the jacketing without the use of a torch or heater.

PITWRAP® B100 jacketing consists of a high-tack butyl adhesive with aluminum film laminated to two polyester films (top and bottom) to assure a high level of resistance and protection (puncture and tear resistance). The polyester layers also protect the aluminum face against corrosion.



Type of Delivery and Storage

Rolls:

- 3.9 in x 49.2 ft (0.1 m x 15 m) or 16 ft² (1.5 m²)
Gross weight: 5.9 to 6.9 lbs (2.7 to 3.1 kg)
- 23.6 in x 49.2 ft (0.6 m x 15 m) or 96 ft² (9.0 m²)
Gross weight: 36.1 to 40.1 lbs (16.4 to 18.2 kg)
- 39.4 in x 49.2 ft (1.0 x 15 m) or 161 ft² (15.0 m²)
Gross weight: 59.9 to 67.2 lbs (27.1 to 30.5 kg)
- Jacketing should not be stored where it may come in contact with hydrocarbon solvents such as petroleum spirit and diesel oil or other organic solvents.
- Jacketing should be handled and stored in a manner as not to damage the material and its packaging. For best results, rolls should be stored vertically; however, the rolls may be stored horizontally in their cartons provided the rolls are not exposed to damage by excessive weight of the stacked materials.
- Jacketing should be protected from inclement weather by storing indoors, where material will not exceed 100°F (38°C) for extended periods. Jobsite storage in well ventilated containers or covered on pallets is suitable for temporary periods.
- Store products in a heated building during cold weather or prior to cold weather application.
- Store away from sparks or flames.
- Consult Safety Data Sheet for additional storage and handling information.

Field Application

Always read and understand information contained within product data sheets and safety data sheets before attempting to use this product. If you have questions regarding fitness of use of this product for an application, consult Owens Corning.

Substrate Preparation

All surfaces should be dry and free of dust, loose scale, oil, grease and frost.

Insulation should be secured to the pipe with fiberglass-reinforced strapping tape, 2 pieces per section, overlapped by at least 50%.

Cellular Glass Application Guidelines

PITWRAP® B100 jacketing may be shop or field-applied. See supplemental application instructions at the end of this document.

Any change in insulation thickness, such as screwed ell covers, pipe step downs, etc., should be field tapered to make a smooth transition. These transitions may be covered with jacketing cut to fit or with spiral wrapped strips of jacketing.

Cleanup and Disposal

Dispose of excess jacketing, release film and packaging in accordance with local, state and federal regulations.

Coverage

Standard application of adhesive to FOAMGLAS® insulation:

The required amount of jacketing for a section of insulated pipe can be calculated* as follows:

- Required Jacketing Area (A)
Equation 1, Imperial Units (23.6 in wide roll)
 $A = [1.08 \times [\pi \times (d + 2t) + 2] \div 12] \times l$
Equation 2, SI, metric Units (1 m wide roll)
 $A = [1.05 \times [\pi \times (d + 2t) + 50] \div 1000] \times l$

Where d = actual pipe diameter in inches or mm, t = insulation thickness in inches or mm, and l = pipe length in ft or m.

*Figures DO NOT include losses.

Limitations

- DO NOT use below ground.
- DO NOT use in areas where jacketing will be exposed to solvents that can dissolve butyl rubber.
- DO NOT allow jacketing to remain exposed to sunlight and/or weather for more than 6 months.
- Not intended for indoor use.

Typical Properties

PROPERTY ¹	METHOD	SI	ENGLISH
Color		Silver (Aluminum)	
Thickness, Total Aluminum Foil + Butyl Rubber Adhesive – Release Film		1.2 ± 0.05 mm	47.3 ± 2 mil
Weight (Nominal), Foil + Butyl – Release Film		1.75 kg/m ²	0.36 lb/ft ²
Application Temperature			
Maximum		45°C	113°F
Minimum		5°C	41°F
Service Temperature ²			
Maximum		140°C	284°F
Minimum		-50°C	-58°F
Tensile Strength	ASTM D1000	≥ 55 N/cm	≥ 31 lb/in
Elongation	ASTM D1000	≥ 30%	
Puncture Resistance	ASTM E154	26 ± 10 kgf	58 ± 22 lbf
Permeance	ASTM E96	≤ 0.23 ng/Pa·s·m ²	≤ 0.004 perm
Water Vapor Permeability	ASTM E96 (Wet Cup)	0.00 ng/Pa·s·m	0.00 perm-in

1 Properties are subject to change. Consult Owens Corning.

2 Service temperature limits are derived from laboratory evaluation of the product. Variations in substrates, loading conditions, or other external factors may further limit service temperature. Always consult FOAMGLAS® Insulation System Specification for suitability for use recommendations for a specific application.

Supplemental Instructions for Field-Applied Jacketing



Step 1
Cut a section of jacketing long enough to fit around the insulated pipe and have a 2 in (50 mm) overlap.



Step 2
Peel 2 in (50 mm) of release film from the jacketing to reveal the butyl adhesive.



Step 3
Apply revealed adhesive to insulation in line with pipe axis. Best results are achieved when the start point results in the overlap terminating in a water shedding position.



Step 4
Apply pressure with plastic spreader to ensure that the butyl adhesive fills the surface cells of the insulation and achieves adhesion without trapping air.



Step 5
Remove release film while applying jacketing around the circumference of the insulation.



Step 6
Remove remaining release film and press jacketing around the circumference to achieve adhesion without trapping air.



Step 7
Apply pressure with spreader to ensure that the jacketing overlap is well adhered and without air bubbles. This completes installation of one section of jacketing.



Step 8
Start subsequent section of jacketing with a 2 in (50 mm) overlap and a 2 in (50 mm) offset from the starting point of the adjacent section. The red line represents the starting point of the subsequent section, which avoids the build-up of more than three layers at the overlap.



Step 9
Continue applying jacketing sections as described above, taking care to overlap and offset the starting point of each section from the previous one.



Step 10
Remove release film while applying jacketing around the circumference of the insulation. Apply pressure with plastic spreader to ensure that the butyl adhesive fills the surface cells of the insulation and achieves adhesion without trapping air.




Step 11
Remove remaining release film and press jacketing around the circumference to achieve adhesion without trapping air.



Step 12
Best results are achieved when overlaps are positioned one above, one below, one above configuration.

Supplemental Instructions for Pre-Applied Jacketing



Step 1
If the insulation is supplied with pre-applied jacketing, then a circumferential butt strip will need to be applied to seal over the joint.



Step 2
Apply butt strip in the same way as the jacketing, peeling the release film away while wrapping the strip around the insulation.



Step 3
Finish the butt strip using the spreader to ensure that the butt strip overlap is well adhered to itself and to the jacketing and without air bubbles.

For additional information on FOAMGLAS® Insulation Systems, please contact Owens Corning or visit us at www.foamglas.com.

The information contained herein is accurate and reliable to the best of our knowledge. But, because Pittsburgh Corning, LLC has no control over installation workmanship, accessory materials or conditions of application, NO EXPRESSED OR IMPLIED WARRANTY OF ANY KIND, INCLUDING THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS MADE as to the performance of an installation containing Owens Corning products. In no event shall Pittsburgh Corning, LLC be liable for any damages arising because of product failure, whether incidental, special, consequential or punitive, regardless of the theory of liability upon which any such damages are claimed. Pittsburgh Corning, LLC provides written warranties for many of its products, and such warranties take precedence over the statements contained herein.

Industrial & Commercial Sales

Americas

+1 800 327 6126

Asia-Pacific

Singapore: +65 9635 9184

China: +86 (0) 21 6101 7179

Japan: +81 3 6365 4307

Europe, Middle East & Africa

+32 13 661 721

Technical Services

Americas & Asia-Pacific

+1 800 327 6126

foamglastechnical@owenscorning.com

Europe, Middle East & Africa

+32 13 611 468

Industrytechnical@foamglas.com



PITTSBURGH CORNING, LLC
ONE OWENS CORNING PARKWAY
TOLEDO, OHIO 43659 USA

Toll Free + 1 800 327 6126

For web-based Sales and Technical Service inquiries, please visit www.foamglas.com